


## Monthly Fee Example



- Step 1: To Calculate ERU's, you add all impervious cover
  - Main Area = 1,205 sf
  - Garage = 338 sf
  - Patio = 150 sf
  - Porch = 100 sf
  - Driveway = 600 sf
  - Total Impervious Cover = 2,393 sf
- Step 2: Divide Total Impervious Cover by 2,700 sf
  - 2,393 / 2,700 = 0.89 ERU's
- Step 3: ERU's are multiplied by \$1.50 for monthly fee
  - 0.89 ERU's x \$1.50 = \$1.34 per month